


## CHIP QUIK® Instructions

### The simple CHIP QUIK® SMD Removal Method using a standard solder iron

CHIP QUIK® Instructions	
	<b>1.</b> Apply Chip Quik flux to all leads of SMD with syringe or flux applicator.
	<b>2.</b> Melt Chip Quik low temperature alloy uniformly on all pins of SMD. Maintain alloy in molten state long enough for complete reflow.
	<b>3.</b> Lift chip from board with dental pick or Vacpick.
	<b>4.</b> Thoroughly clean site with swab dipped in flux while applying heat. Clean thoroughly with alcohol pad.

#### Intructions supplied with CHIP QUIK®

##### SMD REMOVAL

[with solder iron or warm air bath]

- Apply flux to all leads with syringe.
- Melt CHIP QUIK® uniformly on all pins.
- Maintain alloy in molten state long enough to release chip.
- Lift chip from board with dental pick or Vacpick.

##### CLEAN UP

- While molten, use cotton swab and flux to move excess to an unused section of board.
- While applying heat, polish each pad with a swab and flux until thoroughly clean.
- At room temperature clean residue with alcohol pad.
- You are now ready to install the new chip.

**2.5 ft. CHIP QUIK® material, removes 1250 to 1500 SMD pins.**

**PATENT #5.326.016**

[CHIP QUIK® Home Page](#)